


Courtesy & Door Ajar Switches

63-67 Courtesy Switch	1192712	13.75
68-74 Courtesy Switch	1192750	14.95
A 75-82 LH Courtesy Switch	1192752	11.50
B 75-77 RH Courtesy Switch	1192754	7.00
C 78-82 RH Courtesy Switch	1192756	20.50




68-74 Switch Terminal **6 Piece Set** connects the switches to wiring harness **2 reqd** 1192735 8.50
Door Ajar Switches 2 required on all models.

D 68-72 Door Ajar Switch	1192758	21.50
68-76 Switch Mounting Grommet	1192766	4.00
E 73-76 Door Ajar Switch	1192762	12.00
F 77-82 Door Ajar Switch	1192756	20.50
G 70-72 Door Ajar Switch Bumpers Pair Does 1 car. Tapered square with adhesive back.	1192760	6.00

Hood Alarm Switches

H 69-74 Hood Opening Switch	1192758	21.50
------------------------------------	---------	-------



I 75-82 Hood Opening Switch	1192762	12.00
75-82 Switch Bracket 4 Piece Mounting Kit with 2 screws & 2 nuts. Does 1 car.	1192808	3.00

Anti Theft Alarm System

68-Early 70 Lock Cyl Alarm Switch	2826150	22.45
Late 70- Early 77 Lock Cyl Alarm Switch	2826151	27.45
74-Early 77 On-Off Plastic Switch	2485206	24.50
On-Off Switch Mounting Bracket	2826149	6.00
On-Off Switch Mounting Jam Nut	2775288	2.40

Early 77 has a Fender Mounted Alarm Switch
Late 77 has a Door Mounted Alarm Switch

Late 77-82 Door Switches include an Integrated Harness


Late 77-78 LH Door On-Off Switch	2826142	44.00
79-80 LH Door On-Off Switch	2826144	44.00
81-82 LH Door On-Off Switch	2826146	44.00
81-82 RH Door On-Off Switch	2826148	44.00
70-Early 77 Lock Cylinder Switch	2826152	38.50
Late 77-82 Door Lock Switch	2826154	60.00
70-82 Lock Cylinder Switch Mounting Clip	1055042	4.95
70-82 Lock Cylinder Escutcheon	1224828	7.95
70-82 Lock Cylinder Mounting Gasket Pair	1077820	1.95
Late 77-80 Alarm Relay	2826158	45.45
78-82 T-Top Rear Mounting Plate includes Alarm Switch		
78-82 LH Rear Mtg Plate Black repro	1281052	20.00
78-82 RH Rear Mtg Plate Black repro	1281055	20.00
81-82 Alarm Relay	2826160	50.00
81-82 Alarm Controller Module	2826162	173.25
69-82 Alarm Flasher	2892204	6.50
68-82 Flasher Mounting Clip	2892105	8.00
68-82 Alarm Horn Delco replacement	2820513	49.50
68-82 Horn Mounting Nut Plate	1137532	12.50

See Page 167 for 68-82 Alarm Harnesses

Turn Signal Levers

*** Our 53-75 Levers are still made in the USA**

A 53-60 Lever with White oval tip *	2897101	19.95
B 61-62 Lever with White fluted tip *	2897102	19.95
C 63 Lever with Black fluted tip *	2897103	19.95
63 Lever Black Fluted Tip Only NOS discontinued GM	2897100	10.50
D 64-66 Lever with Chrome fluted tip *	2897104	19.95
E 67 Lever with Chrome & Black tip *	2897105	19.95
F 68 Lever or 69 except Tele Lever with Black tip *	2897106	19.95
G 69 with Tele Lever *	2897107	19.95
H Early 69 Tilt Wheel Lever *	2897205	19.95
I Late 69-71 Tilt Wheel Lever *	2897206	19.95
J 70-71 except Tele Lever *	2897108	19.95
K 70-71 with Tele Lever *	2897109	19.95
L 72-74 Tilt Wheel Lever *	2897207	19.95
M 72-74 except Tele Lever *	2897110	19.95
N 72-74 with Tele Lever *	2897111	19.95
75-76 except Tele Lever *	2897120	25.50
75-78 Tilt Wheel Lever	2897208	Disc
O 77 except T&T or Cruise - China Repro	2897121	19.00
O 77 except T&T or Cruise - * NOS	2897112	40.00
P 77 with T&T & Cruise Lever * NOS	2897113	Disc
Q 78-79 except T&T, Cruise Lever *	2897114	22.50
R 78-79 Cruise exc T&T Lever * NOS	2897115	100.00



S 78-Early 79 with T&T & Cruise Lever	2897116	144.50
Early 79 Levers have a 30 Degree Bend Late 79 Levers are Straight.		
T Late 79-80 T&T & Cruise Lever *	2897117	140.00
U 78-82 T&T except Cruise Lever *	2897118	26.85
79-82 Tilt Wheel Lever	2897209	Disc
V 81-82 with Cruise Lever * NOS	2897119	0.00

Directional Switch

NOT RETURNABLE if Factory Seal Broken


55-62 Switch Assembly with color coded harness		
NOS discontinued Genuine GM	2895101	125.00
Repro Switch Assembly USA	2895152	29.50
Repro Switch Assembly Import	2895164	27.25
63 Switch Assembly NOS	2895102	0.00
63 Switch Mounting Screws Pair	2895117	1.50
63 Switch Cable Only	2895148	22.50
63 Switch Cable Mounting Clip mounts the cable to the steering column jacket	2895112	7.50
64-82 Switches include a color coded harness & plugs		
64-66 Switch Assembly except Tele with Upper Bearing NOS Delco Switch Assembly	2895103	102.25
Repro Switch Assembly USA	2895154	75.00
Repro Switch Assembly Import	2895166	49.95
65-66 Switch Assembly with Tele USA	2895104	145.00
65-66 Switch Assembly with Tele Import	2895160	135.00
67-68 Switch Assembly NOS	2895106	150.00
67-68 Switch Assembly Repro USA	2895156	81.50
67-68 Switch Assembly Repro Import	2895168	79.00
69-82 Switch Mounting Screw 3 reqd	2895114	4.40
69-76 Switch Assembly with Tilt & Tele Column NOS in the GM box	2895108	150.00
Repro Switch Assembly USA	2895158	79.95
Repro Switch Assembly Import	2895172	69.95
69-79 Switch Assembly without Tilt & Tele Column or 77-Early 79 Switch with T&T Delco	2895107	48.50
Repro above Switch Assembly USA	2895170	38.95
Early 79 has bent lever; Late 79 has straight lever		
Late 79-88 Switch with T&T Delco	2895110	41.50
Late 79-88 Switch with T&T Repro	2895162	39.95

Solution to a Common 63 Problem

When the lower tip of the directional cable breaks off at the switch, what do you do? Simply move the switch up the column 3/4" and drill a new mounting hole. Cut away a small portion of the cable outer casing & re-mount the inner cable to the directional switch mechanism.

Directional Canceling Cams

W 63 Canceling Cam	2896102	14.50
64-66 Canceling Cam	2896103	13.50
63-66 Cam Mounting Screw Set		
	2896101	1.95
67-68 Cam except Tele	2896104	27.95
69-76 Cam except Tele	2896106	0.00
75-82 Canceling Spring	2896109	18.25



Canceling Cam Actuators

Included with above directional switches. These mount on the directional signal switch & are often broken.

64-66 Canceling Cam Actuators NOS	2896107	19.95
65-66 Tele Canceling Cam Actuator	2896112	30.00
67-68 Tele Canceling Cam Actuator	2896105	27.95
69-79 Canceling Cam Actuator	2896114	22.50

Directional Flasher

X 63-82 Flasher Mounting Clip	2892105	
63-82 Flasher Clip Mounting Screw	2892106	
63-82 Wire Harness Plastic Connector with wire leads use with Directional or 4 way Hazard Flashers	1148100	5.00
Y Directional Flashers		
55-60 Flasher or 63-66 Flasher with back-up Lamps or 69-82 Flasher	2892204	6.50
61-65 Flasher without back-up Lamps or 67-68 Flasher	2892203	6.50
67-77 4 Way Flasher Knob replmnt	2892206	8.00
77-82 4 Way Flasher Outer Knob	2892212	4.00
77-82 4 Way Flasher Push Button	2892214	4.00
77-82 4 Way Button Spring	2892210	3.00

