oOSOEZ Wiring Guides

L@@K at oOSOEZ.com

Full Color and you can look at these without the eye fatigue staring at others

12" x 18" convenient size for actual use inside, under or even behind dash.

Easily ID Circuits, Junctions, Splices, Connectors, Gauges, Colors and Locations plus related Minature Bulb and Fuse ID.

Laminated for garage type hands on use, under the hood, dash or tail lamps

Complete Sets currently available for 1958 through 1976. More to follow.


Economical Have you ever tried to read and understand the factory AIM or schematics? You loose your place before you can even get to the end of the wire. It's so frustrating. What is your time worth?

12.50 each

one testimonial stated - quote

"they're Idiot Proof"

- 8958101 **58** Dash with Fuse Box, Courtesy, Clock, Lighter, Regulator to Generator, Directional Switch
- 8958102 **58** Ignition, Headlamp, Rear, Power Top, Power Window, License, Fuel Injection
- 8959101 **59** Dash with Fuse Box, Courtesy, Clock, Lighter, Regulator to Generator, Directional Switch
- 8959102 **59** Ignition, Headlamp, Rear, Power Top, Power Window, License, Fuel Injection
- 8960101 **60** Dash with Fuse Box, Courtesy, Clock, Lighter, Regulator to Generator, Directional Switch
- 8960102 **60** Ignition, Headlamp, Rear, Power Top, Power Window, License, Fuel Injection
- 8961101 61 Dash with Fuse Box, Courtesy, Clock, Lighter, Regulator to Generator, Directional Switch
- 8961102 **61** Ignition, Headlamp, Rear, Power Top, Power Window, License, Fuel Injection
- 8962101 **62** Dash with Fuse Box, Courtesy, Lighter, Regulator to Generator, Directional Switch
- 8962102 **62** Ignition, Headlamp, Rear, Power Top, Power Window, License, Fuel Injection
- 8963101 **63** Dash with Fuse Box
- 8963102 **63** Ignition, Headlamp, Rear, AC, PW, Tach Buzzer, Back-Up
- 8964101 **64** Dash with Fuse Box
- 8964102 64 Ignition, Headlamp, Rear, AC, PW, TI, FI Solenoid, Aux AC Lamp, Back-Up
- 8965101 **65** Dash with Fuse Box
- 8965102 65 Ignition. Headlamp, Rear, AC, PW, TI, Back-Up, FI Solenoid, Aux AC Lamp
- 8966101 **66** Dash with Fuse Box
- 8966102 66 Ignition, Headlamp, Rear, AC, PW, TI, Aux AC Lamp
- 8967101 **67** Dash with Fuse Box
- 8967102 67 Ignition, Headlamp, Rear, AC, TI, PW, Aux AC Lamp, Speed Warning
- 8968101 **68** Dash with Fuse Box
- 8968102 68 Ign., Headlamp, Rear, AC, TI, Speed Warning, Defogger, Alarm, PW, Carb Solenoid
- 8969101 69 Dash with Fuse Box without AC
- 8969102 69 Dash with Fuse Box with AC
- 8969103 69 Ign, Hdlamp, Rear, AC, AT, TI, Speed Warning, Defog, Alarm, PW, Carb Solenoid
- 8970101 70 Dash with Fuse Box without AC
- 8970102 70 Dash with Fuse Box with AC
- 8970103 70 Ignition, Headlamp, Rear, AC, TI, PW, TCS, Washer Monitor Defogger, Alarm,
- 8971101 71 Dash with Fuse Box without AC
- 8971102 71 Dash with Fuse Box with AC
- 8971103 71 Ignition, Headlamp, Rear, Defogger, TI, AC, TCS Jumper, CEC, Alarm, PW
- 8972101 72 Dash with Fuse Box without AC
- 8972102 72 Dash with Fuse Box with AC
- 8972103 72 Ignition, Headlamp, Rear, Defogger, AC, TCS Jumper, Alarm, PW
- 8973101 73 Dash with Fuse Box without AC
- 8973102 73 Dash with Fuse Box with AC
- 8973103 73 Ignition, Headlamp, Rear, Defogger, AC, TCS Jumper, Alarm, PW
- 8974101 74 Dash with Fuse Box without AC
- 8974102 74 Dash with Fuse Box with AC
- 8974103 **74** Ignition, Headlamp, Rear, Defogger, AC, TCS Jumper, Alarm, PW
- 8975101 **75** Dash with Fuse Box
- 8975103 75 Ignition, Headlamp, Rear, Defogger, AC, Heater, Alarm, PW, Hood Door, Map Lamp
- 8976101 **76** Dash with Fuse Box
- 8976103 **76** Ignition, Headlamp, Rear, Defogger, AT AC, Heater, Alarm, PW, L82 AT Solenoid, Map Lamp



Fusible Links

9

Fusible Links protect wiring harnesses by melting and opening a circuit to prevent damage when an overload of current occurs. Corvettes from 1967-1982 used them to protect the starter, alternator and horn relay circuits. Earliers Corvettes can have these added to prevent damage and fires.

Rule: select a Fusible Link with a smaller gauge than the circuit to be protected. A 14 gauge Fusible Link protects 12 gauge circuit. A 16 gauge Fusible Link protects 14 gauge circuit. An 18 gauge Fusible Link protects 16 gauge circuit.

Fusible Link **14** Gauge 8995212 **4.00**Fusible Link **16** Gauge 8995213 **4.00**Fusible Link **18** Gauge 8995214 **4.00**

Wire Harnesses - See pages 165-166-167